

Installation Instructions

1. Position the hinge, with leaves open, against the rabbet, with the top of the hinge $1/8$ " below the header and $1/4$ " above the saddle for door clearance. Drill a screw hole into the frame at the top of the hinge and secure the leaf with one of the #12 flat-head metal screws provided.
2. After checking that the hinge fits the frame properly, remove hinge and position the door leaf on the door, aligned with the top. Mark and drill enough holes in the door, for the #12 flat-head screws provided.
3. Position the door with hinge attached, at 90 degrees to the frame, shimming the door to line up the hinge with the jamb leaf hole drilled in step 2. Re-secure jamb screw, remove shims and check door for swing and clearance. If door is heavy, you may need to drill and secure several jamb screws.
4. When swing and clearance are correct, drill and secure all remaining screws.

