

Installation Instructions

1. Determine which door is active.
2. Trim astragal as necessary to the size of the door.
3. Install with screws provided on the pull side of the active door. Neoprene seal should be placed where the gap is between the doors.

