



EMAIL

contact@legacyllc.com

C

PHONE

Local: +1 (718) 292-5333 Toll Free: +1 (888) 383-3330

0

WEBSITE LegacyLLC.com

0

ADDRESS 415 Concord Avenue, Bronx, NY 10455

Installation Instructions THRESHOLDS



Aluminum - Bronze
Adjustable - Rabbeted
Carpet Saddles
Interlocking - Custom
Stair Nosing - Diamond
Plate - Stainless Steel
Expansion Joint Plates
Ramps - Thermal Breaks

- **1.** Measure door sill (frame width at bottom) and cut the threshold to extend the full width of the opening.
- **2.** Notch the threshold sides if necessary to accommodate the side jamb stops.
- **3.** Fasten on threshold to the sill with proper screws.
- **4.** Operate the door several times to ensure the threshold does not to inhibit the door from self-closing and latching.